


Preparation Before use



If the instructions are not Followed, personal injury or Property damage may occur

- This product is for DC-12V. (Sure to use the adaptoer included)
- Be sure to turn off the tap water before installation
- Checking hot & cold water, be sure to install in cold water side valve
- Install on a flat Floor
- After installation, Turn on the raw water and check for Watre leaks
- Avoid near Magnetic (magnetic) Substances
- It should be installed in a well ventilated environment
- It should be installed wherer raw water is easily supplied
- Put drain hose in the sink

Name of Each part (Main body)



Under sink Hydrogen Water system

UNDER SINK HYDROGEN WATER SYSTEM

USER MANUAL





What is Hydrogen Water ?

Clean water rich in Hydroigen removes free radicals that are harmful body. You can expect ther effect to protect your health

- Please read the user manuaek carefully abd use it correctly.
- The Warranty card is included in this User's manual, So please keep it



Name of Each part (FAUCET)



Under sink Hydrogen Water system

How to use the Product

Obtaining Hydrogen water 1cup



1. Touch "HYDROGEN 1CUP" button.
2. It automatically stops after the set one cup amount is dispensed

How to set the Initial one cup dispensing capacity

1. Please provide a cup to the outlet for the desired one cup amount
2. Press and hold the one cup dispensing switch more than 2 sec.
3. Water coming out at the same time as the switch-operation sound
4. Release the switch when the desired amount of water is dispensed
5. The Initial one-cup serving capacity has been saved (Auto setting)

Obtaining Purified water



1. Touch "PURIFIED" button.
2. Press again "PURIFIED" button to stop he after getting desired amount outlet


How to use the Product

Obtaining Hydrogen water



1. Touch "HYDROGEN" button.
2. Press again "HYDROGEN" button to stop the after getting desired amount outlet

Cotrol volume




1. Hold the 'hidden button', for 3seconds to set Volume
2. After choosing the desired V olume, As the button is pressed, it will switch in the following order, (1 ~ 6)
3. When the desired level is selected, the setting is automatically completed after 5 seconds.

<< Volume setting stage >>

- 1Level : Button sound 1st
- 2Level : Button sound 2st
- 3Level : Button sound 3st
- 4Level : Button sound 1st + ment 1st
- 5Level : Button sound 2st + ment 2st (Initial value)
- 6Level : Button sound 3st + ment 3st

Installation example (Main body +Faucet)



Product Specifications

Product	Under sink Hydrogen Water system
Amount of water	0.8 ~ 1.5 l /min
Product Weight	About 5.0 kg
Product Measurement	W 100 × D 410 × H155 mm
H2 (ppb)	600~1,500ppb
pH	Normal
ORP(mV)	-100 ~ -600mV
Rated Voltage	IN : AC100~240, 50/60Hz , OUT : DC12V, 10A
Power Consumption	Standby power : 0.3W ↓ , Power Consumption : 100W ↓

The information (appearance, design and specification) specified in this product manual may be modified without notice in order to enhance quality of the product.

